## **USERS MANUAL**

#### **DIGITAL MULTIMETER**



Before using the instrument, please read this manual carefully, and save it well for future using.

Statement1
Safety Statement1
Safety Instructions2
Safety Operation Specifications3
Safety Symbols 8
<i>Overview</i> 10
Instrument panel description10
FUNC. key11
Data hold11
Maximum/minimum measurement 12
Backlight12
Flashlight12
Auto power off12
Input LED indication function 13
High voltage/large current prompt
function13
Measurement operation14
DC/AC voltage measurement 14

DC/AC voltage mV measurement	15
Frequency/Duty measurement	16
DC/AC current measurement	17
Resistance measurement	18
Capacitance measurement	18
Continuity measurement	19
Diode measurement	20
NCV test	20
Live test	21
Temperature Measurement	22
General Technical Specifications	23
Accuracy Specifications	25
DC voltage	25
AC voltage	26
DC current	27
AC current	28
Resistance	29
Capacitance	30

Frequency/Duty	31
Diode test	33
Continuity test	33
Temperature	34
laintenance	35
Clean	35
Replace Battery and Fuse	36

#### Statement

In accordance with the international copyright law, without permission and written consent, do not copy the contents of this manual in any form (including storage and retrieval or translation into languages of other countries or regions). The manual is subject to change in future edition without prior notice.

## Safety Statement

It requires that you must be careful during the execution of the operation. If incorrectly perform the operation or do not follow the procedure, it may damage the instrument or equipment. In the

circumstances that such conditions are not met or not fully understood, please do not continue to perform any operation indicated by the caution mark.

⚠ "Warning" mark indicates the condition and operation which may cause danger to users.

It requires that you must pay attention during the execution of this operation. If incorrectly perform the operation or do not follow the procedure, it may result in personal injury or casualties. In the circumstances that such conditions are not met or not fully understood, please do not continue to perform any operation indicated by the warning mark.

#### Safety Instructions

The instrument is designed according

to the requirements of the international electrical safety standard IEC61010-1 for the safety requirements of the electronic testing instruments. The design and manufacture of instruments strictly comply with the requirements of IEC61010-1 CAT.IV 600V, CAT.III 1000V over voltage safety standards and pollution level 2.

## Safety Operation Specifications Marning

In order to avoid possible electric shock or personal injury and other safety accidents, please abide by the following specifications:

 Please read this manual carefully before using the instrument, and pay special attention to safety warning information.

- Strictly observe the operation of this manual and use this instrument.
   Otherwise, the protection function of the instrument may be damaged or weakened
- Please be careful if the measurement exceeds 30V AC true RMS, 42V AC peak or 60V DC. There may be danger of electric shock at this kind of voltage
- By measuring the known voltage to check whether the meter work is normal, if it is not normal or damaged, do not use it again.
- Before using the instrument, please check whether there is any crack or plastic damage in the instrument case.
   If so, do not use it again.
- Before using the instrument, please

- check whether the probe is cracked or damaged. If so, please replace the same type and the same electrical specifications.
- The instrument shall be used in accordance with the specified measurement category, voltage or current rating.
- Please comply with local and national safety code. Wear personal protection equipment (such as approved rubber gloves, masks and flame retardant clothes, etc.) to prevent being damaged by electric shock and electric arc due to exposed hazardous live conductor.
- When it shows low battery indicator, please replace the battery in time in case of any measurement error.

- Do not use the instrument around explosive gas, steam or in wet environment.
- When using the probe, please put your fingers behind the finger protector of the probe.
- When measuring, please connect the zero line or the ground line firstly, then connect the live wire; but when disconnecting, please disconnect the live wire firstly, then disconnect the zero line and ground line.
- Before opening the outer cabinet or battery cover, please remove the probe on the instrument. Do not use the instrument in the circumstances that the instrument is taken apart or battery cover is opened.

• It only meets the safety standards when the instrument is used together with the supplied probe. If the probe is damaged and needs to replace, the probe with same model number and same electrical specifications must be used for replacement.

## Safety Symbols


4	High voltage warning	
~	AC (Alternating current)	
	DC (Direct current)	
≂	AC or DC	
$\triangle$	Warning, important safety signs	
÷	Ground	
ф	Fuse	
	Equipment with double	
	insulation/reinforced insulation	
	protection	
•	Battery under voltage	
CF	Product complies with all relevant	
6	European laws	

	The additional product label shows that		
Ī	do not discard this electrical/electronic		
_	product into household garbage.		
Class II measurements are suitable f			
	testing and measuring circuits directly		
CAT. II	connected to power points (sockets and		
	similarities) of low voltage power		
	installations.		
Class III measurement is suita			
	testing and measuring circuits connected		
CAT. III	to the distribution part of low voltage		
	power supply devices in buildings.		
	Class IV measurements are suitable for		
	testing and measuring circuits connected		
CAT. IV	to the power supply of low voltage power		
installations in buildings.			

#### **Overview**

A new generation of 20,000-count, true RMS, high-performance, automatic range digital altimeter with analog strip. New display and function layout, large LCD display is clearer and better user experience; with high voltage light alarm, input LED prompt function. It is the best choice for professional electricians, enthusiasts or home use.

## Instrument panel description



- NCV probe
- ② Flashlight
- 3 Red / green light
- 4 LCD display (Dual color backlight)
- 5 Function keys
- (6) Function knob
- (7) Other measurement input socket
- 8 COM Input socket
- mA/μA Input socket
- 10A Input socket

## FUNC. key

When there are multiple measuring functions on a gear, the "FUNC." key switch function is adopted.

#### Data hold

Press "HOLD" key, enter data hold mode/cancel data hold mode.

#### Maximum/minimum measurement

Press the MAX/MIN key to enter the maximum measurement, and then press the loop to display the maximum and minimum values. Press and hold for more than 2 seconds to cancel the maximum/minimum measurement mode.

## **Backlight**

Press key, turn on backlight/turn off backlight.

## **Flashlight**

Press key, and keep more than 2 seconds to turn on the flashlight / turn off flashlight.

#### Auto power off

 There will be no operation in 15 minutes, the instrument will turn off automatically to save battery energy. After automatic

- shutdown, press any key to restore the working state of the instrument.
- If you press the "FUNC." button and turn on the meter power, the automatic shutdown function will be cancelled.
   After turning off the meter, the meter is reopened to restore the automatic shutdown function

#### Input LED indication function

When power on or function switching, the corresponding input light flashes to prompt the user to insert the input port of the probe.

## High voltage/large current prompt function

When the measuring voltage is greater than 80V or the measuring current is greater than 1A, the orange backlight will light up, prompting the users to be careful.

## Measurement operation



- The voltage above DC1000V or AC750V can't be measured; otherwise the instrument may be damaged.
- Pay special attention to safety when measuring high voltage to avoid electric shock or personal injury.
- Test the known voltage with the meter before use, confirm the instrument function is intact.

#### DC/AC voltage measurement

- Turn the knob to "Hz\vec{v}" and switching AC or DC voltage function by "FUNC." key
- 2) Plug the red meter into the " vantz%LiveC/F"

- input and the black meter into the "COM" input.
- Contact the probe to the measured circuit (connect to the measured power supply or circuit in parallel), measure the voltage.
- Read the measurement result on the screen. When measuring AC voltage the frequency is displayed on LCD simultaneously.

# Note: When the voltage is greater than 80V, the orange backlight will light up. DC/AC voltage mV measurement

- Turn the knob to "╬\overline{w}" and switching AC or DC voltage function by "FUNC." key
- 2) Plug the red probe into the "volude " volude " " input and the black probe into the "COM" input.

- Contact the probe to the measured circuit (connect to the measured power supply or circuit in parallel), measure the voltage.
- Read the measurement result on the screen. When measuring AC voltage the frequency is displayed on LCD simultaneously.

## Frequency/Duty measurement

- Turn the knob to "Hz%" and switching frequency or duty function by "FUNC." key.
- Plug the red probe into the "volute "volute | volute | v
- Contact the probe to the measured circuit (connect to the measured power supply or circuit in parallel), measure

- the frequency and duty.
- 4) Read the measurement result on the screen.

#### DC/AC current measurement

- 1) Turn the knob to "译和" or " 嵩 " or " 줍hz" and switching AC or DC current function by "FUNC." key
- Insert the red probe in "μA/mA" socket or "10A" Socket. Insert the black probe in "COM" socket.
- Disconnect the power of the tested circuit; connect the meter to the circuit under test, then turn on the circuit power supply.
- Read the measurement result on the screen. When measuring AC current, the frequency is displayed on LCD simultaneously.

Note: the orange backlight is on when the measured current is greater than 1A.

#### Resistance measurement

- Turn the knob to "♀" and switching resistance function by "FUNC." key
- 2) Plug the red probe into the "volute like" input and the black probe into the "COM" input.
- Contact the probe to the measured circuit or resistor, measure the resistance.
- 4) Read the measurement result.

## Capacitance measurement

- 1) Turn the knob to "If".
- 2) Plug the red probe into the "volute " input and the black probe into the "COM" input.

- Contact the probe to the measured capacitor.
- Read the measurement result on the screen.

## **Continuity measurement**

- 1) Turn the knob to "a; and switch to continuity function by "FUNC." key.
- 2) Plug the red probe into the " volutificative red input and the black probe into the "COM" input.
- Contact the probe to the measured circuit or resistor.
- 4) If the resistance or circuit of the measured resistance is less than  $30\Omega$ , the buzzer will on and the green indicator lights up at the same time. When the resistance is about between  $30\Omega$  to  $60\Omega$ , the red indicator lights up.

The LCD displays the resistance.

#### Diode measurement

- Turn the knob to "<sup>♀</sup>; " and switch to diode measurement function by "FUNC." key.
- Insert the red probe in "volution " socket.
   Insert the black probe in "COM" socket.
- Touch the diode anode with the red probe, the black probe contacts the diode cathode.
- Read the measurement result on the screen.
- If the probes is opposite to the diode polarity, the meter displays "OL", which can be used to distinguish the anode and cathode of two.

#### NCV test

1) Turn the knob to the "NCV" and switch to

- NCV test function by "FUNC." key. The meter will display "NCV".
- Then NCV probe gradually approaches the detected point.
- When the meter senses weak AC signals, the green indicator lights up, at the same time, the beeps send out slow dips.
- When the meter senses strong AC signals, the red indicator lights up, at same time, the beeps send out fast dips.

#### Live test

- Turn the knob to the "NCV", and switch to live wire test function by "FUNC." key. The meter will display "Live".
- 2) Insert the red probe in "volute live" socket.

  Then the red probe contact to the test

point.

 When the meter senses strong AC signals, it will display "Live" and the orange indicator lights up, at same time, the beeps send out fast dips.

#### **Temperature Measurement**

- 1) Turn the knob to the "c/r".
- 2) Insert the K thermocouple into the instrument. The thermocouple's positive (red) is inserted into the "vohtsklivet/F" input, and the negative end (black) is inserted into the "COM" input.
- Contact the measured object with the thermocouple probe and read the 22

result from the display.

 Celsius and Fahrenheit are shown simultaneously on the display.

Note 1: The cold junction of thermocouple is placed inside the instrument, and it needs longer heat balance with the measuring environment.

Note 2: Using K type thermocouple probe.

## General Technical Specifications

 Environment condition of using: CAT. IV 600V; CAT. III 1000V; Pollution level 2, Altitude < 2000m Working environment temperature and humidity:

- $0\sim40^{\circ}\text{C}$  ( <80% RH, <10°C non condensing)
- Storage environment temperature and humidity:
- -10~60°C ( <70% RH, remove the battery)
- Temperature coefficient: 0.1× accuracy /°C (<18°C or >28°C)
- MAX. Voltage between terminals and earth ground: DC1000V/AC750V
- Fuse protection: μA/mA: F200mA/250V
   10A: F10A/250V
- Sampling rate: approx. 3 times/second.
- Display: 20000 counts.
- Over range indication: "OL".
- Low battery indication: " " will be displayed.
- Input polarity indication: automatically

display "-".

Power requirement: 2 x 1.5V AA batteries.

## **Accuracy Specifications**

The accuracy applies within one year after the calibration

Reference condition: the environment temperature 18°C to 28°C, the relative humidity is no more than 80%,

accuracy: ± (% reading + word) .

#### DC voltage

Range	Resolution	Accuracy
200mV	0.01mV	
2V	0.0001V	
20V	0.001V	±(0.08% +5)
200V	0.01V	
1000V	0.1V	

Input impedance: 10MΩ

Overload protection: 1000V DC or 750V

AC;

#### AC voltage

Range	Resolution	Accuracy
200mV	0.01mV	
2V	0.0001V	
20V	0.001V	±(1.0%+25)
200V	0.01V	
750V	0.1V	

Input impedance: 10MΩ

Overload protection: 1000V DC or 750V

AC;

Frequency Response: 40Hz ~ 1kHz;

**TRMS** 

#### DC current

2004			
Range	Resoluti	Accuracy	
	on		
200μΑ	0.01μΑ		
2000μΑ	0.1μΑ	±(0.5%+5)	
20mA	0.001mA	(U.570+5)	
200mA	0.01mA		
10A	0.001A	±(1.0%+15)	

Overload protection:

μA/mA: F200mA/250V fuse

10A: F10A/250V fuse

Maximum input current: μA/mA: 200mA;

A: 10A

When measuring >1A current, the continuous measurement time shall not

exceed 30 seconds. When measuring current again, the instrument shall be cooled for twice the measurement time.

#### **AC** current

Range	Resoluti on	Accuracy
200μΑ	0.01μΑ	
2000μΑ	0.1μΑ	. (4.00( .05)
20mA	0.001mA	±(1.0%+25)
200mA	0.01mA	
10A	0.001A	±(1.5%+25)

Overload protection:

μA/mA: F200mA/250V fuse

10A: F10A/250V fuse

Maximum input current: µA/mA: 200mA;

A: 10A

## Frequency Response: 40Hz ~ 1kHz;

#### **TRMS**

When measuring >1A current, the continuous measurement time shall not exceed 30 seconds. When measuring current again, the instrument shall be cooled for twice the measurement time.

#### Resistance

Range	Resolution	Accuracy	
200Ω	0.01Ω		
2kΩ	0.0001kΩ		
20kΩ	0.001kΩ	±(1.0% +15)	
200kΩ	0.01kΩ		
2ΜΩ	0.0001ΜΩ		
20ΜΩ	0.001ΜΩ	. (0.00( .05)	
100ΜΩ	0.01ΜΩ	±(3.0% +25)	

Overload protection: 250V

## Capacitance

Range	Resolution	Accuracy
2nF	0.0001nF	
20nF	0.001nF	
200nF	0.01nF	
2uF	0.0001uF	+(4.00/ +50)
20μF	0.001μF	±(4.0%+50)
200μF	0.01μF	
2mF	0.0001mF	
20mF	0.001mF	

Overload protection: 250V

Frequency/Duty

· roquonoy/Buty			
Range	Resolution	Accur acy	Sensi tivity
200Hz	0.01Hz		
2kHz	0.0001kHz	±(1.0%	100mV
20kHz	0.001kHz	+30)	(RMS)
200kHz	0.01kHz		
2MHz	0.0001MHz	±(1.0%	
		+30)	0.8V
10MHz	0.001MHz	±(3.0%	(RMS)
		+30)	
1~99%	0.1%	±(3.0%	
		+30)	

Minimum measurement frequency: 5Hz Overload protection: 250V

## Frequency measurement in mV gear:

- 1) Range: 10Hz ~ 100 kHz
- 2) Sensitivity: >10mV RMS, sine wave

## Frequency measurement in V gear:

- 1) Range: 10Hz ~ 20 kHz
- 2) Sensitivity: >0.5V RMS, sine wave

## Frequency measurement in current gear:

- 1) Range: 10Hz ~ 20 kHz
- 2) Sensitivity:
- μA: >100μA RMS, sine wave
- m: >10mA RMS, sine wave
- A: >1A RMS, sine wave

#### **Diode test**

<b>→</b>		MAX test current:			
	It displays the	about 1.2mA.			
	approximate forward	MAX test voltage:			
	voltage value of the	about 3.0V.			
	diode.	Overload			
		protection: 250V.			

**Continuity test** 

	The resistance is <30,					
	the buzzer will sound and	Test voltage is				
	the indicator light is	about 1.0V.				
-1))	green. When the	Overload				
	resistance >30 and <60,	protection:				
	the buzz does not ring,	250V				
	the indicator light is red.					

## **Temperature**

Tomporataro					
Unit	Resol ution	Range and Accuracy			
$^{\circ}$	0.1℃	-40℃~0℃	± 3℃		
		0 ℃ ~	±(1.0%+		
		400℃	2℃)		
		400 ℃ ~	± 2.0%		
		1000℃			
		-40°F∼ 32°F	± 6°F		
°F	<b>1</b> °F	32 °F ~ 752	±(1.0%+		
		°F	<b>4</b> °F)		
		752 °F ~ 1832 °F	± 2.0%		

The accuracy does not include the error of the thermocouple probe.

## Maintenance Clean

If there's dust on the terminal or the terminal is wet, it may cause measurement error. Please clean the instrument according to the steps below:

- Switch off the power supply of the instrument, and remove the test probe.
- 2) Turn over the instrument and shake out the dust accumulated in the input socket. Wipe the outer cabinet with a damp cloth and mild detergent, do not use abrasive or solvent. Wipe contacts in each input socket with a clean cotton swab soaked in alcohol.

## ⚠ WARNING

Please always keep the inside of the instrument clean and dry to avoid electric shock or instrument damage.

## Replace Battery and Fuse Replace Battery:

- Turn off the power supply of the instrument, and remove the probe on the instrument.
- Use screwdriver to unscrew screws fixing the battery cover, remove the battery cover.
- 3) Remove old batteries, replace with new batteries of the same specifications. Please note the polarity of the battery according to the positive and negative polarity marks

- inside of the battery cover.
- Install the battery cover to its original position, fix and lock the battery cover with screws.

## **⚠** WARNING

- To prevent electric shock or personal injury caused by error reading, please replace the battery promptly when the battery power is low. Please do not make battery short circuit or reverse battery polarity to discharge the batteries.
- To ensure safety operation and product maintenance, when the instrument will not be used for an extended period of time, please

remove the batteries to avoid any product damage caused by battery leakage.

#### Replace Fuse

- Turn off the power supply of the instrument, and remove the probe on the instrument.
- Use screwdriver to unscrew screws fixing the back cover, and remove the back cover.
- Remove the burnt fuse, replace with new fuse of the same specifications, and ensure that the fuse is clamped in the safety clip.
- Install the back cover, fix and lock it with screws.

## ⚠ WARNING

To avoid possible electric shock, personal injury or instrument damage, please use the fuse with same specifications or specified specifications.









